Simplicity 5 in the second sec

PARTS MANUAL MODEL 6000 ATTACHMENTS & ACCESSORIES

36" SNOW THROWER MFG, NO. 1690169 30" ROTARY TILLER MFG. NO. 1690194 42" SNOW PLOW & DOZER BLADE MFG. NO. 1690085 42" SNOW PLOW & DOZER BLADE HITCH MFG. NO. 1690188 VACUUM COLLECTOR MFG. NO. 1690226 36" VACUUM COLLECTOR ADAPTOR MFG. NO. 1690228 42" VACUUM COLLECTOR ADAPTOR MFG. NO. 1690227 VACUUM COLLECTOR CART COVER MFG, NO. 1600395

ROVING NOZZLE MFG. NO. 1690031 REAR GRASS CATCHER MFG. NO. 1690229 HOUR METER MFG. NO. 1690197 DUMP CART MFG. NO. 1600236 LIFT LEVER MFG. NO. 1690195 **HUB CAPS** MFG. NO. 1600027 **HUB CAPS** MFG. NO. 1690181 WINTERIZING KIT MFG. NO. 1690151

Attention Dealers:

This manual is one of the new style parts manuals which Simplicity is issuing. We trust you will find that this manual contains more information than previously offered in parts manuals, including important facts which will help you with repair work and parts ordering.

The new loose-leaf format allows for easier updating of specific sections should it be necessary and, in general, makes the manual easier to work with in day to day use.

For quick, accurate reference when making warranty claims, group numbers are now given with each parts section. Also note that serial numbers of units are now listed to locate any difference in parts which may occur in later models. Be aware of these unit serial numbers when ordering parts.

Standard torques appear in a chart at the end of the manual, while important individual torques are given on specific parts drawings. These provide easy reference notes for repair and troubleshooting.


CRITICAL and MAJOR notations point out important facts or instructions which relate to safety or reliability and machine quality. The CRITICAL notation (C) pinpoints characteristics which, if not properly, followed, can create a safety hazard. The MAJOR notation (M) marks characteristics which, if not properly followed, may result in operating failure, shortened product life, or greatly reduced quality of the unit.

We are confident that you will find that these new format parts manuals contain more complete information for your benefit, and that they are much easier to use.


Simplicity Technical Publications

Table of Contents

36" SNOW THROWER	. 2
BODY & ROTOR GROUP	
DRIVE GROUP	. 4
SPOUT & MISC. GROUP	
PUSH BAR & PTO GROUP	
30" ROTARY TILLER	. 10
DEFLECTOR & TINE GROUP	
DRIVE & CLUTCH GROUP	
HITCH & LIFT GROUP	, 14 . 16
42" SNOW PLOW & DOZER BLADE	
42" SNOW PLOW & DOZER BLADE HITCH	
LIFT LEVER	. 22
DUMP CART	. 24
REAR GRASS CATCHER	. 26
VACUUM COLLECTOR	. 28
HOUSING & ENGINE GROUP	. 28
MISC. GROUP	
ROVING NOZZLE,	
36" VACUUM COLLECTOR ADAPTOR	
42" VACUUM COLLECTOR ADAPTOR	. 34
VACUUM COLLECTOR CART COVER	
HOUR METER	. 38
HUB CAPS	. 38
HUB CAPS ,	
WINTERIZING KIT	
STANDARD HARDWARE TORQUE SPECIFICATIONS Inside Back Co	ver




Ref.	Part					11-7
No.	No.	Ωtγ.	Serial No.		Description	
1	106491	1	(00000)-[)	8EARING	
2	106774	1	1-(00000)	j.	DEFLECTOR	
3	161247	1	1-(00000)	1	DECAL, Safety	
4	907727	2	1-(00000)	}	CAPSCREW, 1/4-20 x 5/6	
5	916622	9	(OOODD)-()	NUT, Hex, 1/4-20	
6	916964	2	J-(00 00 00)	1	LOCKWASHER, 1/4	
7	917356	10	[00 00 0]-{	1	LOCKWASHER, 5/16	
8	917372	10	(00000)-(J	NUT, Hex, 5/16-18	
9	919318	4	(00000)-{	}	CAPSCREW, Hex, 5/16-18 x 5/8	
10	924856	1	1-(00000)	- }	SCREW, Self-tapping, 5/16-18 x 1/2	
11	1654936	1)-(00000)	1	BODY AND FRAME ASSEMBLY	
12	106653	1	{ 00000 }-{]	SPROCKET	
13	106771	1	(00000)-{	}	STUD	
14	1068 6 3	1	(00000)-()	SCRAPER, Body	
15	106856	1	(00000)-(1	ROTOR	
16	151040	1	(00000)-(]	KEY, Hi-pro	
17	171221	1	(00000)-(]	SIDE PLATE	
18	172278	2	(00000)-(1	FLANGE, Brg.	
19	172279	2	(00000)-(1	FLANGE, Brg., w/fitting	
20	173934	2	(00000)-(}	BEARING, Cartridge, (w/Setscrew)	
21	177434	2	(00000)-(1	\$KID	
22	177565	2	(00000)-()	CLIP, Frame	
23	916950	4	(00000)-(]	NUT. 3/8-16	
24	916965	4	(00000)-()	LOCKWASHER, 3/8	
25	917377	2	(00000)-()	WASHER, Plain, 1/4	
26	917378	4	(00000) (1	WASHER, Plain, 3/8	
27	917397	6	(000001-(1	CAPSCREW, Hex Hd., 5/16-18 x 3/4	
28	920676	4	(00000)-(]	CAPSCREW, Hex Hd., 7/16-14 x 1	
29	921959	7	(00000)-()	CAPSCREW, Hox Hd., 1/4-20 x 5/8	
30	922110	4	(00000)-()	BOLT, Carriage, 3/8-16 x 3/4	
31	92 3362	2	(00000)-(1	LOCKNUT, 5/16-18	
32	925205	2	(000000)-(1	CAPSCREW, Hex Hd., 5/16-18 x 5/8	
33	928691	1	1000001-{	1	SETSCREW, Skt. 5/16-18 x 5/16	
34	930650	4	{00000}-{	1	NUT, Flange, 2-way Lock, 7/16-14	
35	928352	1	(00000)-()	LOCKNUT, Flange, 3/8-16	




NOTE: USE STANDARD HARDWARE TORQUE SPEC. NO. 173209 UNLESS OTHERWISE NOTED.

11-76


Ref. No.	Part No.	Oty.	Serial No.		Description
1	106771	1	(00000)-()	\$TUD
2	106860	1	(00000)-{	1	SHAFT ASSEMBLY
3	108514	1	(000000)-(;	V-8ELT, 110.1"
4	171211	1	(00000)-(GUARO, Belt
6	171220	1	(00000)-(- 1	GUARO, Chain
6	171242	1	(agooo))	CHAIN
7	17124B	1	(00000)-()	PULLEY
8	176161	2	(00000)-(1	CLAMP, Housing
ġ	905123	1	(00000)-(]	KEY, Woodruff, No. 9, 3/16 × 3/4
10	916950	3)-(addob)-(i i	NUT, 3/8-16
11	916965	3	1-(00000))	LOCKWASHER, 3/8
12	917356	3	1-(00000)	1	LOCKWASHER, 5/16
13	917372	3	1-(00000)	1	NUT, 5/16
14	917378	1	(00000)-()	WASHER, Plain, 3/8
15	921210	1	(00000)-(þ	CAPSCREW, Hex Hd., 3/8-16 x 1
16	921221	1	(00000)-()	CAPSCREW, Hex Hd., 5/16-18 x 1 1/2
17	922127	2	(00000)-()	CAPSCREW, Hex Hd., 5/16-18 x 1 3/4
18	923428	2	(ODDOO)-(•	NUT, Full Lock, 3/8-16
19	928352	1	(00000)-(1	NUT, Flange Lock, 3/8-16
20	928721	1	[00000]-(1	SETSCREW, Sq. Hd., 5/16-18 x 1/2
21	106864	1	(000001-0	1	BEARING, Housing
22	154258	2	(00000)-(1	BEARING, Needle
23	921133	1	1-(00000)]	FITTING, Grease
24	8061012	7	1-(00000)]	WASHER



Ref.	Part						
Na.	No.	Ωty.	Serial No	-	Description		
1	171362	1	(00000)-(j	ÇABLE ASŞEMBLY		
2	171382	1	(00000)-(•	CLAMP		
3	176333	1	(00000)-(•	ROD ASSEMBLY, Spout Control		
4	176934	ī	(00000)-()	HANDLE GRIP		
5	927428	1	(00000)-()	SCREW, Washer Hd., Taptite, 1/4-20 x 3/8		
6	106229	2	(00000)-()	WING NUT		
7	106760	1	{00000]-()	EXTENSION, Spout		
8	106762	1	(00000)-(1	SPOUT ASSEMBLY		
9	106788	6	(00000)-()	CLIP, Spring		
10	121175	1	(00000)-(}	GUIDE, Liner		
11	152050	1	{000000}-{	.1	GUIDE, Rod		
12	156306	6	(00000)-(}	PIN		
13	165073	2	(00000)-()	CLIP, Speed		
14	171379	1	{00000}-(J	WASHER, Cup		
15	172432	1	{00000}-{]	CAP, Fuel Tank, Winterized		
16	177567	1	(000001-1	}	SUPPORT, Bracket		
17	907729	1	(00000)-(1	CAPSCREW, Hex Hd., 5/16-18 x 1 1/4		
18	917356	1)-{0D00G)	}	LOCKWASHER, 5/16		
19	917372	1	}-{0 000 00})	NUT, Hex, 5/16-18		
20	917377	7	(00000)-[)	WASHER, Plain, 1/4		
21	917378	2	(00000)-{	,	WASHER, Plain, 3/8		
22	920562	2	(00000)-(,	BOLT, Carriage, 5/16-18 x 3/4		
23	921210	2	1-(00000)	1	CAPSCREW, Hex Hd., 3/8-16 x 1		
24	922000	2	1-(00000)	,	PIN, Cotter		
25	923362	1	1-(00000))	LOCKNUT, 5/16		
26	928710	2	1-(00000)	í	LOCKWASHER, Pyramidal, 3/8		
27	930601	2	(00000)-(í	SCREW, Hex Washer Hd., Taptite, 5/16/18 x 5/8		
28	930645	2	(00000)-()	NUT, Flange, 3/8		
29	930647	1	(00000)-(i	LOCKNUT, 9/16-18		
30	1654634	1	(00000)-(i	INTERLOCK SWITCH		
31	1656658	2	1-(00000)	- 1	STOP, Belt		




Ret.	Part					
No.	No.	Qtγ.	Serial No.		Description	
1	101096	1	(00000)-(ŀ	PULLEY	
2	106787	1	(00000)-()	SPRING, Clip	
3	154177	2	(00000)-()	SPACER	
4	158227	2	(00000)-()	SPACER	
5	159159	1	(000D0]-(1	\$PRING	
6	162034	1	1-(00000))	GUIDE ASSEMBLY, Clutch Hod	
7	162115	1	1-(00000)	1	STOP, Balt	
8	1656632	1	1-(00000)	;	SPRING	
9	171247	1	(00000)-(•	PULLEY, Idler	
10	916621	1	1-(00000)		NUT, Na. 10-24	
11	916950	4	(00000)-(1	NUT, 3/8-16	
12	916965	4	(00000)-{)	LOCKWASHER, 3/8	
13	917356	1	(00000)-(1	LOCKWASHER, 5/16	
14	917365	1	1-(00000)	1	LOCKWASHER, No. 10	
15	917642	7	1-(00000)	-	WASHER, Plain, 5/16	
16	919361	2	(00000)-(}	CAPSCREW, Hex Hd., 3/8-16 x 1 3/4	
17	923422	2	(00000)-()	NUT, Full Lock, 5/16-18	
18	926267	1	(00000)-()	SCREW, Flat Hd., No. 10-24 x 5/8	
19	930579	2]-{00000}	F	CAPSCREW, Hex Hd., 3/8-16 x 1 1/4	
20	1610590	1	(00000)-{	ŀ	BRAKE SHEAVE	
21	1654779	1)-(aopao)	ŀ	PUSH BAR ASSEMBLY	
22	1654780	1	(00000)-{	- 1	BRACKET	
23	1654781	1)·(00000)	1	ROD	
24	1655037	1	1-(000001	1	STUD	
25	1655333	1	1-(00000)	•	PIVOT PULLEY ASSEMBLY	
26	8191022	1	(00000)-(}	COLLAR, Set	
27	928804	1	(ODDOO)-(•	SETSCREW, 1/4-20 x 3/8	




Simplicity 11-76


Ref.	Part					11-76
No.	No.	Qty.	Serial No.		Description	
1	105273	1	{0 00 00]-()	PLATE END, Deflector, L.H.	
2	105274	1	(00000)-()	PLATE END, Deflector, R.H.	
3	118053	2	{000000}-()	PIN	
4	8152001	8	(00000)-()	TINE BLADE, L.H.	
5	927557	20	1-(00000))	NUT, Hex, Flange, 5/16-18	
6	918451	3	(00000)-(1	PIN, Cotter, 1/8 x 3/4	
7	920562	2	(00000)-()	BOLT, Carriage, 5/16-18 x 3/4	
8	8152002	8	(00000)-()	TINE BLADE, R.H.	
ġ	923700	10	1-(00000))	BOLT, Carriage, 5/16-18 x 1/2	
10	925359	4	(ODDDQ)-()	SCREW, Taptite, 5/16-18 x 3/4	
11	1657317	2	(00000)-()	DECAL, Sefety	
12	1657318	1	(00000)-()	DECAL, Drive Control	
13	930685	8	(00000)-1	1	80LT, Carriage, 5/16-18 x 5/8	
14	1655658	1	(ODOQO)-{)	DEFLECTOR	
15	1656087	1	(00000)-()	BAR, Reinf., L.H.	
16	1656088	1	1-(00000)	}	BAR, Reinf., R.H.	
17	920488	16	1-(00000)	}	CAPSCREW, Hex, 7/16-20 x 1-1/4	
18	928867	16	(00000)-(}	LOCKNUT, Hex, 7/16-20	
19	1656040	2)-(a o oa)-)	HUB & PLATE ASSY, Tine	



					
Ref. No.	Part No.	Qty.	Serial No.	-	Description
-					1541.55
1	1657499	1	[00000]-[ŀ	SPRING
2	905123	2	1-[00000]	ŀ	KEY, Woodruff, No. 9, 3/16 x 3/4
3	908295	4	1-[00000])	CAPSCREW, Hex, 1/4-20 x 1/2
4	925204	1	(000001-1)	CAPSCREW, Hex, 3/8-16 x 1
5	923358	4	(00000)-()	LOCKNUT, Hex, Full, 1/4-20
6	930645	1	(00000)-()	LOCKNOT, Hex, Full, 3/8-16
7	923428	3	(00000)-1	1	LOCKNUT, Hex, Full, 3/8-16
8	1656085	1	(00000)-1	1	GUARD, Belt-Pulley
9	1657023	1	(00000)-1	1	PULLEY (Driven)
10	170395	1	(00000)-()	PULLEY, (Driver)
11	1655815	1	(00000)-(}	LEVER ASSY, Clutch
12	908127	1	(00000)-(ŀ	CAPSCREW, Hex, 3/8-16 x 3/4
13	916950	4	(ddddd)-(- 1	NUT, Hex, Full, 3/8-16
14	916965	4	(00000)-(•	LOCKWASHER, 3/8
15	917356	1	[00000]-()	LOCKWASHER, 5/16
16	917372	1	(00000)-()	NUT, Hex. Full, 5/16-18
17	917642	11	(ODDOO}-()	WASHEA, Plain, 5/16
18	919357	2	(00000)-()	CAPSCREW, Hex, 3/8-16 x 7/8
19	930255	1	(00000)-(1	SCREW, Lock, Flange, 5/16-18 x 3/4
20	1656003	1	(00000)-(]	STOP, Belt
21	154534	2	(00000)-(]	PULLEY, Idler
22	163011	1	(00000)-{		V-BELT
23	174561	1	100000)-(]	PULLEY, Idler
24	917402	2	1-(00000)	J	CAP\$CREW, Hex, 3/8-16 x 2
25	1655650	1	1000001	ŀ	LINK, Clutch
26	1610404	5	(OODDO)-()	SPACER
27	1655998	1	(00000)-(•	PIN
28	1655999	1	(00000)-()	BRACKET, Pulley Support
29	1656000	1	(000000)-{	1	SUPPORT, Pulley
30	1656084	1	}-{0D00 0 }-{)	GUARD, Idler Pulley
31	918196	2	(00000)-(1	CLIP, Pin
32	919360	1	1-(00000)	1	CAPSCREW, Hex, 3/8-16 x 1-1/2
33	1 655 6 51	1	100000)-1	1	PIN, Lock
34	1655819	1	(00000)-(ł	BRACKET, Pulley
35	918213	1]-(00000)	ŀ	NUT, Hex, Full, 7/16-14
36	928731	1	[00000]-[þ	LOCKNUT, Hex, Half, 3/8-16
37	1655 649	1	[00000]-(1	CLEVIS ASSY, Adj.
38	921971	1	[000001-0	,	CAPSCREW, Hex, 3/8-16 x 1-3/4




Ref. Part Description Oty. Serial No. No. No. (000001-0 WASHER 105010 4 1 2 105386 2 1-(00000) SPACER WASHER, Special 3 157424 2 (000000)-((00000)-{ FLANGE, Bearing 4 161069 4 5 170022 1-(00000)-[GASKET, Case 1 (000001-0 SPACER, Case 6 170029 1 7 170030 $\{000000\}$ -(SHAFT ASSY, Tine 8 170053 1 (000000)-(CHAIN ROLLER (00000)-(9 170177 1 10 170368 z 1-(00000) WASHER 170369 J-(00000)-L SPACER 11 1 2 BEARING 12 170419 1-(00000)-L NUT, Rex, Full, 1/4-20 4 (00000)-(13 916622 4 (00000)-(LOCKWASHER, 1/4 916964 14 15 917356 16 1000001-0 LOCKWASHER, 5/16 NUT, Hex, Full, 5/16-18 16 917372 16 1-(00000) CAPSCREW, Hex, 5/16-18 x 5/8 (00000)-{ 17 919318 10 CAPSCREW, Hux, 1/2 - 13 x 5 1-(000000) 920272 1 18 (00000)-1 CAPSCREW, Hex, 3/8-16 x 2-1/4 19 922130 1 922134 (00000)-(LOCKNUT, Hex, Full. 1/2-13 20 1-(00000) BOLT, Carriage, 5/16-18 x3/4 21 923346 В 923428 1000001-0 LOCKNUT, Hex, Fult, 3/8-16 22 1 3 $\{000000\}.$ BOLT, Carriage, 1/4-20 x 3/4, Gr. 5 23 931317 24 1655644 1 (ODDOO)-{ FRAME & HITCH ASSY BEARING 25 1656089 2 (00000)-1FLANGE, Bearing 1655814 4 (00000)-[26 CASE ASSY, Half, R.H. 27 1655824 1 1-(00000) 1 1655827 (00000)-(SHAFT ASSY, Drive 28 1 CASE ASSY, Half, L.H. 29 1655830 1 (00000)-(WASHER, Flat, 1/4 30 917377 1 $\{000000\}$ 1 BOLT, Carriage, 1/4-20 x 1-1/4 931320 1-1000001-L } 31 1 923358 (000000)-1LOCKNUY, Full, Hex. 1/4-20. 32



NOTE: USE STANDARD HARDWARE TORQUE SPEC. NO. 173209 UNLESS OTHERWISE NOTED.


Ref.	Part						
No.	No.	Qty.	Serial No.		Serial No.		Description
ı	106788	1	(00000)-{)	CLIP, Hair Pin		
2	157427	2	(00000)-1)	KEY, Square		
3	919262	2	(00000)-1	- 1	NUT, Hex, Jam, 1/2 x 20		
4	921221	2	(00000)-(ŀ	CAPSCREW, Hox, 5/16-18 x 1-1/2		
5	928709	2	(00000)-(- 1	SCREW, Set, Sq.Hd., 5/16-18 x 3/8, Gr. 8		
6	1655654	1	(00000)-()	LEVER ASSY, Lift		
7	1655831	1	(00000)-()	ROD, Lift		
8	1655832	1	(00000)-1)	PIN, Hitch		
9	1655965	1	1-(00000))	BRACKET ASSY, Draw Bur		
1D	1656375	1	[00000]-(ŀ	TUBE ASSY, Guide		
11	918196	3	{ 00000 0}-(ŀ	PIN, Quick		



NOTE: USE STANDARD HARDWARE TORQUE SPEC. NO. 173209 UNLESS OTHERWISE NOTED.

11-76


Ref. No.	Part No.	Oty. Serial No.		-	Description
1	107024		(00000)-(,	SHOE ASSEMBLY
2	107045	1	1-1000001-1)	PI,ATE WEAR
3	107047	1	1-(00000)]	BLADE ASSEMBLY
4	916950	10	(D00D0)·I	ŀ	NUT, Hex Full, 3/8-16
5	916965	10	(0 00 00)-(þ	LOCKWASHER, 3/8
6	923232	4	(00000)-(,	BOLT, Carriage, 3/8-16 x 1
7	923347	6	1000001-4	j	BOLT, Carriage, 3/8 -16 × 3/4





11-76


Ref. No.	Part No.	Ωtγ.	Serial No		Description
1	156306	4	(00000)-(ŀ	PIN
2	176012	6	(00000)-()	CLIP, Pin, Safety
3	1603601	1	(00000)-(]	PIN, Pivat
4	1603602	1	(00000)-(ŀ	Pity, King
5	1607911	1	(00000) (- 1	BAR ASSEMBLY, Push
6	1657663	2	1-10000001	j	BRACKET ASSY
7	10678B	1	1-[000000]	i	CLIP, Spring
8	922130	2	(00000)-()	CAPSCREW, 3/8-16 x 2-1/4
9	930645	2	(00000)-(í	LOCKNUT, Flange, 3/8-16



NOTE: USE STANDARD HARDWARE TORQUE SPEC. NO. 173209 UNLESS OTHERWISE NOTED.

Ref.	Part					11-76
No.	No.	No. Ωty.	Serial No	٠.	Description	
1	106787	1	{00 00 01-(ì	CLIP, Spring	
2	153058	1	1000001-1	i	PIN	
3	171011	1	(00000) (i	SPRING	
4	917356	5]-(00000)	i	LOCKWASHER, Spring, 5/16	
5	917372	5	(00000)-(1	NUT, Hex, 5/16-18	
6	918113	1	(00 00 0)-1	1	PIN, Spring, 3/8 x 1	
7	921332	5	(00000)-(i	CAPSCREW, Hex, 5/16-18 x 3/4	
8	928709	3	(00000)-(í	SCREW, Set, Sq. Hd., 5/16-18 x 3/8	
9	1651055	1]-(00000)	i	SPRING	
10	1650157	1	(D000D)-1	j	BUTTON	
11	1651496	1	(00000)-1	j	GUIDE ASSY, Rod	
12	1651702	1	(00000) (j	GRIP, Lift Lever	
13	1657840	1	(00000)-(j	LEVER ASSY, Lift	
14	1655986	1	(00000)-(j	SUPPORT, Shuit	
15	1655997	1	(00000)-[)	QUADRANT, Lift	
16	1656737	1	(00000)-(]	HOD, Latch	
17	1656741	1	(00000)-()	ROD, Lift	
18	1657648	1	(00000)-(j	LATCH, Lever	
19	8021010	1	(00000)-{)	COLLAR, Sei	
20	8301042	2	(00000)-{)	COLLAR, Set	
21	106788	2]-(00000)	1	Ct.IP, Hair Pin	


Simplicity 5 cm




NOTE: USE STANDARD HARDWARE TORQUE SPEC. NO. 173209 UNLESS OTHERWISE NOTED.



Ref. Part Νo. No. Oty. Serial No. Description 1)-(0**000**0)-(102005 1 PLATE, Box Guide 2 102024 1)-(000000)-(PIVOT, Box assy. 3 102027 1 (00000)-(AXLE ASSEMBLY 4 102035 1 1-(00000) FRAME ASSEMBLY 5 102037 1 (00000)-(TONGUE ASSEMBLY 6 102040 1 10000001-0 PLATE, Box Catch 7 102051 1 1-[00**00**01] CLEVIS ASSEMBLY 8 102075 1 1-(00000) SPRING, Torsion . 9 170320 2 1-(00000) WHEEL & TIRE ASSEMBLY 10 2 102052 1000000)-(11 2 153038 (00000)-(TUBE, 4.00 x 8 12 156316 4 1-[00000] BEARING 13 170319 2 1-(00000) WHEEL 14 8151076 2 1-(00000) BUSHING 15 102004 2 (00000)-(PIN, Pivot 16 105249 1 1-(00000) PIN17 907731 2 (00000)-(CAPSCREW, Hex. 3/8-16 x 1 18 916950 ß (00000)-(NUT, Hex Full, 3/6-16 19 916965 6 1000000]-1 LOCKWASHER, 3/8 20 91737B 3 1-(00000) WASHER, 3/8 21 917398 2 (00000)-(CAPSCREW, 5/16-18 x 1 3/4 22 917400 2 (000000)-1 CAPSCREW, Hex. 3/8-16 x 1 1/4 23 918196 3 1-(00000)-1PIN, Quick 24 2 918433 1-(00000) WASHER, Plain, 3/4 25 2 918459 (00000)-[PIN, Cotter, 3/16 x 1 1/2 26 919362 2 (00000)-1 CAPSCREW, Hex, 3/8-16 x 2 1/4 27 923362 2 (00000)-(NUT, Hex Full, 5/16-18 28 923428 1 1-(00000) NUT, Hex Full, 3/8-16 29 930596 1 (00000)-(CAPSCREW, Hex, $3/B-16 \times 23/4$ 30 1655704 1]-(00000) TRAILER & END GATE ASSY. 31 102002 (00000)-[1 **BODY**, Trailer 32 102003 (00000)-(GATE END




Ref.	Part					11-76
No.	No.	Oty.	Serial No		Description	
	1055000		1000001 /		**************************************	
1 2	1655628 1656053	1	(00000)-(ŀ	BAFFLE ASSY	
3			(00000)-l)	8AFFLE ASSY, Discharge	
4	1656446	1	{00 00 D}-{)	ADAPTOR, Mawer	
5	1656451	2 1	(00000)-(BLADE	
	1656599		(00000)-(1	FRAME ASSY, Bag	
6 7	1656643	1	1-[00000]	•	BAG, Grass	
	1656650	1	1-[00000])	TUBE, Discharge	
8 9	1656980	1	(00000) I)	DEFLECTOR	
10	1656982	1	(00000)-())	DECAL, Warning	
11	1656990	1	(00000)-(COVER ASSY	
	932938	13	(000001-()	WASHER, 11/64 x 1/2 0.D.	
12	925637	10	(00000)	J	RIVET, Blind, 5/32	
13	1656615	1	(00000)-(}	SCREEN	
14	158227	2	(00000)-())	SPACER	
15 10	176012	1	(00000)-(-	PIN, Clip, Safety	
16 17	909055	15	(00000)-(]	LOCKWASHER, No. 10	
18	916622	3	(00000)-()	NUT, Hex. 1/4-20	
19	916950	2 22	(000000)-(]	NUT, Hex, 3/6-16	
20	923906		(00000)-1]	WASHER, 3/16	
21	9169 6 4	3 2	(00000)-(]	LOCKWASHER, 1/4	
22	916965	1	(00000)-(}	LOCKWASHER, 3/8	
22 23	917356 017330	-	(DDDDD)-(}	LOCKWASHER, 5/16	
23 24	917372	1	(00000)-1	} }	NUT, Hex, 5/16-18	
2 4 25	917377 917 3 87	6	}-(00000)-{]-(00000)	,	WASHER, 1/4	
26 26	917415	0 15	(00000)-(,	WASHER, 3/8 NUT, Hex, No. 10-32	
27	921961	3	(00000)-(,	CAPSCREW, Hex, 1/4-20 x 1-1/4	
28	922121	15		,	SCREW, Phil. No. 10-32 x 3/8	
29	922783	1	{00000}-{ 1-{00000}-{	,	BOLT, Carriage, 5/16-18 x 3/4	
30	922110	2	(00000)-(í	BOLT, Carriage, 3/8-16 x 3/4	
31	923856	3	{00000}-(- (SCREW, Hex, Taptite, 5/16-18 x 1/2	
32	930579	2	(00000)-(j	CAPSCREW, Hex, 3/8-16 x 1-1/4	
33	1656620	1	1-(00000)	í	SUPPORT ASSY, Frame	
34	931941	3	(0 0 000)-(,	NUT, Push On	
35	1656684	4	(00000)-(;	CLIP, Cover	
36	1030001	1	(00000)-(í	COVER	
37	1656696	i	(000001-(j	ANGLE, Screen	
				-		



NOTE: USE STANDARD HARDWARE TORQUE SPEC. NO. 173209 UNLESS OTHERWISE NOTED.




Ref.	Part					
No.	No.	Oty.	Serial No.		Description	
	rododo		(appeal)			
1	123095	1	(00000)-(,	PLATE, Engine	
2	123144	1	(00000)-(!	WASHER, Special, 21/64 x 1-1/4	
3	157081	4	(00000)-(!	SPACER	
4	159085	4	(00000)-1	J	CONNECTOR, Cushion	
5	905850	1	(00000)-(ł	KEY, 3/16 x 3/16 x 1	
6	917356	29	(00000)-(ŀ	LOCKWASHER, Spring, 5/16	
7	917372	24	(00000)-{	ŀ	NUT, Hex, 5/16-18	
8	919933	4	(DOODD) (ŀ	CAPSCREW, 5/16-18 x 1-1/2	
9	928721	1:	1-(00000)		SCREW, Set, Sq. Hd., Cup. Pt., 5/16-18 x 1/2	
10	932850	í	1-(00000)		LOCKNUT, Pipe, No. BL -50	
11	1654907	1	(000001-(SPACER	
12	1656968	1	(00000)-(FRAME ASSY	
13	1656972	1	(00000)-()	PLATE, Housing Support	
14	1656973	1	(00000)·(,	HOUSING	
15		1	1000001-0	j	ENGINE, Briggs & Stratton, 4 H.P.	
16	1657332	1	{000000}-(,	FAN ASSY	
17	1657456	4	(00000)-(j	BAR ASSY	
18	927927	1	(OODDO)-{	j	CAPSCREW, 5/16-24 x 1	
19	1657460	1	(00000)-(j	STRAP, Ground	
20	1657477	1	1-(00000)	í	SHIELD ASSY, Muffler	
21	1657505	1	(00000)-(í	MUFFLER	
22	921982	4	(00000)-(i	CAPSCREW, 5/16-24 x 1-1/4	






11-76


Ref.	Part				
No.	No.	Qty.	Serial No.		Description
		_			
1	917378	2	{000000}-{)	WASHER, Plain, 3/8
2	928866	2	(00000)-(1	SCREW, Rd. Hd., 1/4-20 x 3
3	1657402	1	(00000)-(]	HOSE ASSY, Outlet, 6" Dia.
4	930579	2	(00000)-(}	CAPSCREW, Hex.Hd., 3/8-16 x 1-1/4
5	1657403	1	(00000)-{	1	HOSE ASSY, Inlet, 7" Dia.
6	123065	1 .	(00000)-(1	CLAMP, Hose
7	123067	1	(D0000)-(1	CLAMP, Hose
8	158227	2	(00000)-()	SPACER
9	176012	ţ	(000001-0)	CLIP, Pin Safety
10	916622	2	(000001-()	NUT, Hex, 1/4-20
11	916964	2	(00000)-{)	LOCKWASHER, Spring, 1/4



NOTE: USE STANDARD HARDWARE TORQUE SPEC. NO. 173209 UNLESS OTHERWISE NOTED.

Ref.	Part No.					11-76
No.		Oty.	Serial No.		Description	
					· · · · · · · · · · · · · · · · · · ·	
1	123065	1	(D OOD ()-()	CLAMP, Hose	
2	123111	1	(00 0 00)-(ŀ	FLANGE, Hose	
3	123127	1	(00000)-(- 1	HOSE ASSY	
4	123128	2	(00000)-(- 1	CLAMP, Hose	
5	123129	1	(00000)-()	HANDLE, Hose	
6	916622	1	(0 000 0)-(1	NUT, Hex, 1/4-20	
7	916964	1	(00000)-(,	LOCKWASHER, Spring, 1/4	
8	917356	2	(00000)-(1	LOCKWASHER, Spring, 5/18	
9	917397	2	(00 00 0)-(1	CAPSCREW, Hex Hd., 5/16-18 x 3/4	
10	918468	2	(00000)-()	NUT, Wing, 5/16-18	
11	928866	1	(000001-0)	SCREW, Rd. Hd., 1/4-20 x 3	







11-76


Ref. No.	Part No.	Qty.	Serial No		Dascription
1	1657007	1	(00000)-(J	ADAPTOR, 42" Mower
2	917356	1	(00000)-()	LOCKWASHER, Spring, 5/16
3	917372	1	(00000)-(1	NUT, Hex, 5/16-18
4	917642	2	(00000)-()	WASHER, Plain, 5/16
5	920564	1	(00000)-()	BOLT, Carriage, 5/16-18 x 1-1/4
6	931942	2	(00000)-()	NUT, Push, 3/8
7	8161199	2	(00000)-()	WASHER

Mfg.No. 1690228

36" Vacuum Collector Adaptor


11-76

Ref. No.	Part No.	Qty.	Serial No		Description
1	1657188	1	(00000)-(ì	ADAPTOR, 36" Mower
2	917356	1	(00000)-(ŀ	LOCKWASHER, Spring, 5/16
3	923325	1	(00000)-(j	CAPSCREW, Hex. 5/16/18 x 7/8
4	930 6 59	1	(0000D)-(j	NUT, Retainer, 5/16-18
5	931642	2	[00000]-[}	NUT, Push, 3/8
6	81 61 199	3	1-(00000)	F	WASHER




NOTE: USE STANDARO HARDWARE TORQUE SPEC. NO. 173209 UNLESS OTHERWISE NOTED.

Ref.	Part					11-76
No.	No.	Qty.	Serial No	-	Description	
1	177917	1	(00 00 0)-(ŀ	COVER, Cart	
2	178187	2)-(00000)	}	PANEL, Side	
3	178188	2	(DOODD)-{	}	BAIL	
4	178191	2	(00000)-{	}	BAR, Reinf., Side	
5	178192	2	1-(00000)	•	BAH, Reinf., End	
6	159134	6	1-(00000)	•	WASHER, Special	
7	163065	2	(0 00 00)-(;	STOP, Belt .	
8	170000	2	(00000)-()	LATCH	
9	170001	2	(aaaaa)-(,	LATCH, Rad	
10	170002	. 2	(00000))	LEVER	
11	170134	6	(000000)-(1	LINK, Repair	
12	178189	4	1-(00000))	PIN	
13	178190	1	(00000)-{)	BRACKET	
14	178198	2	(000000)-(1	BRACKET	
15	916950	4	(0 000 0)-()	NUT, Hex. 3/8-16	
16	917378	8	(00000)-()	WASHER, Plain, 3/8	
17	917397	4	(00000)-(ì	CAPSCREW, Hex Hd., 5/16-18 x 3/4	
18	91740 0	1	(00000)-1	}	CAPSCREW, Hex Hd., 3/8-16 x 1-1/4	
19	917642	6	(00000)-(1	WASHER, Plain, 5/16	
20	918452	2	(00000)-(}	PIN, Cotter, 1/8 x 1	
21	923362	4	(00000)-(1	NUT, Hex Lock, 5/16-18	
22	923428	8	(00000)-1	}	NUT, Hex,Full Lock, 3/8-16	



Group <u>981000</u>-

Hour Meter



38




11-76

Ref. No.	Part No.	Oty.	Serial No	•	Description
1 2	156210 156211	2	[00000]-((00000)-()]	CAP, Hub CAP, Hub, Front

Mfg. No. 1690197


Hour Meter

Ref. No.	Part No.	0	e-: N-		Description
IVQ.	ryg.	City.	. Serial No.		Description
4	1.20002		(annon) /	,	METER H
ı	172993		(00000)-(,	METER, Hour
2	172996	7	(00000)-()	ADAPTOR
3	1656083	1	(-100000))	WIRE ASSY
4	172998	1	1-(00000)	1	WIRE, Moter to Ground
5	1655592	1	(00000)-(]	CONNECTOR ASSY
6	921880	1	(000000)-(ŀ	LOCKWASHER, External Tooth, 1/4
7	916622	1	(00000)-(]	NUT, Hex, Full, 1/4-20



Group <u>981460-</u>

Hub Caps





11-76

Ref. No.	Part No.	Qty.	Serial No		Dascription
1 2	106/98 170252	1	(00000)-(1	CAP, Winterize(L FILM, Shiple
3	1651562	í	(00000))	DEFLECTOR, Heat

Mfg. No. 1690181

Hub Caps

11-76

Ref. No.	Pert No.	Qty.	Serial No.		Description	
1 2	156210 1655625	2 2	(00000)-((00000)-()	CAP, Front Hub CAP, Hub	

		•		
,				
	•			

į.			

		٠.		

TORQUE SPECIFICATION FOR STANDARD MACHINE HARDWARE

Tolerance ±10%

SIZE	SAE GRADE #2	SAE GRADE #5	SAE GRADE #8 ↔
8-32	19 In./Lbs.	30 In./Lbs.	41 In./ Lbs.
8-36	20 "	31 "	43 "
10-24	27 "	43 "	60 "
10:32	31 "	49 "	68 "
1/4-20	66 "	8 Ft/Lbs.	12 Ft./Lbs.
1/4-28	76 "	10 "	14 "
5/16-18	11 Ft/Lbs.	17 "	25 "
5/16-24	12 "	19 "	25 "
3/8-16	20 "	30 "	45 "
3/8-24	23 "	35 "	50 · "
7/16-14	30 "	50 "	70 "
7/16-20	35 "	55 "	80 "
1/2-13	50 "	75 "	110 "
1/2-20	55 "	90 "	120 "
9/16-20	65 "	110 "	150 "
9/16-18	75 "	120 "	170 "
5/8-11	90 "	150 "	220 "
5/8-18	100 "	180 "	240 "
3/410	160 "	260 "	386 "
3/4-16	180 "	300 "	420 "
7/8-9	140 "	400 "	600 "
7/8-14	155 "	440 "	660 "
1-8	220 "	580 "	900 "
1-12	240 ' "	640 "	1,000 "

NOTES:

- These torque values are to be used for all Simplicity hardware excluding: Locknuts, self-tapping screws, thread forming screws, and sheet metal screws.
- Unless otherwise noted on assembly drawings all torque values must meet this specification.

BOLT HEAD MARKING

S.A.E. GRADE:







		-;
		ý.
		:
	•	
	-	
·		
		· !
·		
		-
	·	